

UNLOCK ENDLESS POSSIBILITIES

YOUR MULTI-PURPOSE INFLATABLE FLOATING DOCK



SIZE

8FT X 6FT X 6"

CAPACITY

1100
LBS

PRESSURE

8-10
PSIG

Water Entertainment Series 

Thank you

FOR CHOOSING US

ABOUT US

We are a vibrant and innovative North American pool essentials brand, dedicated to transforming backyard moments into luminous family memories through smart, energy-conscious designs that spark joy and redefine aquatic elegance.

BRAND MISSION

We exist to illuminate the heart of home by transforming pools into radiant hubs of connection. Through intuitive, adaptive lighting that mimics nature's warmth—from golden twilight glows to moonlit serenity—we craft environments where splashes become laughter, quiet dips spark conversations, and every evening swim strengthens family bonds. Our mission is to turn backyards into emotional sanctuaries, where cutting-edge technology fades into the background, leaving only the magic of togetherness. Because the truest light we create isn't in the water—it's in the memories families build beneath its glow.

Our Brands

Zenhagu[®]
Jeavle[®]

FOXLUX[®]

Foxpool[™]

Generalman[®]

Pondvita[™]

PRODUCT STRUCTURE



• Handle

• D-ring

• Valve



Floating Dock



Hand Pump

PACKAGING



LIST



Storage Bag

tie-down strap




Soft Ladder

Nylon Rope




Repair Kit

⚠ BEFORE INFLATING



INFLATE MODE

- The button is in a popup state.
- After inflation, the valve will automatically close, allowing the product to maintain its inflated state.



DEFLATE MODE

- The button is in a pressed down state.
- The inflation valve will continue to leak air, causing the product to be unable to maintain its inflated state.



Spring pops up, inflated state



Connect the **upper** port of the pump



Attach the hose to the air valve

HOW TO INFLATE



Inflate the float to **8-10 PSIG**



Disconnect from the float




Cover the air valve



Press the valve to release air



Connect the **lower** port of the pump



Attach the hose to the air valve

HOW TO DEFLATE



Release the remaining air



Cover the air valve



Fold and store the float

TRANSPORTATION & STORAGE

- **RELEASE PRESSURE IN CAR:** If leaving your float in the car or strapping it to the roof, release some air to reduce pressure and allow for expansion.
- **AVOID DIRECT SUNLIGHT:** Try to avoid storing your float in direct sunlight as it may result in fading of the colours over time.
- **KEEP COOL ON HOT DAYS:** Keep the float in the shade to prevent pressure increase and UV damage. If no shade, cool it in the water regularly.
- **STORE DEFLATED:** When storing your float, deflate it and store it loosely rolled or unrolled to prevent creases and damage.
- **BAG STORAGE:** You can store your board inside the bag or not. Deflating over winter may cause wrinkles, but they will disappear when re-inflated.
- **AVOID EXTREME TEMPERATURES:** Store your float in a garage, shed, or attic, avoiding extreme temperatures. Ideal storage temperature is between 39~104 °F.

MAINTENANCE

- **CHECK INFLATION PRESSURE:** If you leave your float inflated, check the pressure before each use. Air temperature and pressure changes can affect it.
- **CLEAN AFTER USE:** Rinse your float with fresh water after each use to remove salt, sand, and other debris. Dry it thoroughly before storing to prevent mold and mildew.
- **INSPECT REGULARLY:** Regularly check your float for any signs of wear, tear, or damage. Repair any small punctures or leaks immediately to prevent them from worsening.
- **AVOID SHARP OBJECTS:** Keep your float away from sharp objects and rough surfaces that could puncture or scrape it.
- **AVOID OVERINFLATION:** Do not overinflate your float as it can cause excessive stress on the seams and material, leading to potential damage.

HERE TO HELP

We hope that you have an amazing time on the water

We're always here to help, so if you ever have any questions about your kit or need any general advice, please feel free to get in touch.

customer@foxluxpool.com